

DSLRKIT DMW-BLG10 BLG10E DMW-BLE9 USB Battery Charger 欧盟产品说明书（PDF可 下载版）

PRODUCT USER MANUAL (Brief Version)

Product Name

DSLRKIT DMW-BLG10 BLG10E DMW-BLE9 USB Battery Charger
For Panasonic DMC-GX7, GF6 Cameras

1. Description

The DSLRKIT DMW-BLG10 BLG10E DMW-BLE9 USB Battery Charger is a professional and portable charging accessory, specially designed for Panasonic DMW-BLG10, DMW-BLG10E, DMW-BLE9 lithium-ion batteries, and perfectly compatible with Panasonic DMC-GX7 and GF6 mirrorless cameras. It adopts a standard USB charging interface, supporting wide voltage input (5V 1-2A) from various USB power sources such as power adapters, power banks, computers and car chargers, making it convenient for outdoor and indoor charging anytime and anywhere. The charger features an intelligent charging management system, which automatically identifies the battery type, realizes constant current and constant voltage charging, effectively protecting the battery from over-charging, over-voltage, over-current, short-circuit and over-temperature damage, extending battery service life. It is made of high-quality flame-retardant ABS plastic, compact and lightweight, with a clear LED indicator light to show charging status (red for charging, green for fully charged), allowing users to check the charging progress at a glance. This charger is suitable for photography enthusiasts and professionals who use Panasonic DMC-GX7 or GF6 cameras, solving the trouble of battery power shortage during outdoor shooting, and it complies with EU USB charging standards and safety regulations.

- Application: Charge Panasonic DMW-BLG10, DMW-BLG10E, DMW-BLE9 lithium-ion batteries; compatible with Panasonic DMC-GX7, GF6 cameras; suitable for indoor and outdoor photography scenarios.

- Compatibility: Exclusively for Panasonic DMW-BLG10, DMW-BLG10E, DMW-BLE9 batteries; perfectly matches Panasonic DMC-GX7, GF6 mirrorless cameras (not compatible with other battery or camera models).

- Input & Output Parameters: USB input 5V 1-2A (compatible with most USB power sources); charging current 600mA-800mA (intelligent adjustment); LED indicator (red=charging, green=fully charged/standby).
- Design: Standard USB charging interface (compatible with USB Type-C/Lightning/USB-A via corresponding cables), compact and portable, LED charging indicator, intelligent charging control, easy to operate.
- Material: High-quality flame-retardant ABS plastic (flame-retardant, anti-aging, impact-resistant) + precision metal contacts (stable conductivity, anti-oxidation).
- Function: Intelligent constant current/constant voltage charging, over-charge/over-voltage/over-current/short-circuit/over-temperature protection, LED charging status display, portable USB-powered, extends battery service life.

2. Intended Use

- For charging Panasonic DMW-BLG10, DMW-BLG10E, DMW-BLE9 lithium-ion batteries, ensuring stable power supply for Panasonic DMC-GX7, GF6 cameras during indoor and outdoor photography.
- Suitable for photography enthusiasts, professional photographers and daily users who use Panasonic DMC-GX7 or GF6 mirrorless cameras, especially for outdoor shooting where power sockets are inconvenient.
- Used to replace damaged or mismatched chargers for Panasonic DMW-BLG10/BLG10E/BLE9 batteries, providing a portable and safe charging solution for camera batteries.
- Not for use with non-Panasonic DMW-BLG10/BLG10E/BLE9 batteries (even if the size is similar); not for charging other camera models; not for use with USB power sources exceeding 5V 2A; not for disassembly or modification of the product itself.
- Exclusively compatible with Panasonic DMW-BLG10, DMW-BLG10E, DMW-BLE9 lithium-ion batteries and DMC-GX7, GF6 cameras, not applicable to other battery or camera models.

3. Safety Instructions

- Before use, check whether the battery model matches (Panasonic DMW-BLG10/BLG10E/BLE9) and confirm that the charger and battery are intact, avoiding damage to the battery or charger caused by mismatched models.
- Do not disassemble, knock, drop or step on the charger to avoid damage to the internal circuit, poor contact or short circuit; do not use sharp tools to scratch the shell or metal contacts.
- Keep the charger away from water, damp environments and high-temperature areas (such as near stoves, radiators), avoid short circuit, leakage or damage to internal components caused

by moisture and high temperature.

- Keep away from children under 14 years old to prevent accidental electric shock, swallowing small parts or damage to the product; do not let children touch the metal contacts of the charger or battery.
- When connecting or disconnecting the USB cable, hold the plug (not the cable) to avoid cable breakage, poor contact or short circuit; unplug the USB cable in time when not in use for a long time.
- If the charger has abnormal phenomena such as overheating, peculiar smell, smoke or abnormal LED indicator during use, immediately disconnect the USB power source and stop using it, and contact after-sales service for inspection, do not repair it by yourself.
- Do not use the charger with damaged USB cable, shell or metal contacts to avoid poor contact, short circuit or damage to the battery; replace the damaged parts in time if necessary.

4. How to Use

1. Check that the DSLRKIT charger, USB cable and Panasonic DMW-BLG10/BLG10E/BLE9 battery are intact, and confirm that the battery model matches the charger.
2. Insert the battery into the charger correctly (align the battery contacts with the charger's metal contacts), ensure that it is inserted in place and does not shake; do not forcefully insert the battery to avoid damaging the contacts.
3. Connect one end of the USB cable to the charger's USB port, and connect the other end to a USB power source (5V 1-2A), such as a power adapter, power bank or computer; the charger's red LED light lights up, indicating that charging has started.
4. When the battery is fully charged (usually 2-3 hours), the charger's LED light turns green; remove the battery in time to avoid over-charging and extend battery service life.
5. After charging, disconnect the USB cable from the power source first, then take out the battery from the charger, and install it into the Panasonic DMC-GX7 or GF6 camera for use.
6. Place the charger and USB cable in a dry and cool place for storage after use; avoid placing them with metal objects to prevent short circuit.

5. EU Compliance Information

- EU Responsible Person: CET PRODUCT SERVICE LTD.
- Address: Osterholzallee 144, 71636 Ludwigsburg, Germany
- Tel: +497-1416432236
- Email: info.cetservice@gmail.com

- This product complies with EU General Product Safety Regulation (GPSR), EU USB charging standard EN IEC 62680-1-3:2021 and relevant EU electrical safety standards.

6. Storage & Maintenance

- Store the charger in a dry, cool and ventilated place when not in use; avoid direct sunlight, high temperature, humidity and corrosive environments to prevent aging, deformation or internal circuit damage.
- After use, wipe the surface of the charger, USB cable and metal contacts with a soft dry cloth to remove dust and stains; do not use water, alcohol, gasoline and other corrosive cleaning agents to avoid damaging the shell and internal components.
- Regularly check the USB cable, charger shell and metal contacts for damage, looseness or oxidation; tighten loose parts in time, and replace damaged parts if necessary to ensure safe use.
- Avoid placing heavy objects on the charger or USB cable to prevent deformation, breakage or poor contact; do not bend the USB cable excessively.
- Store the charger with its USB cable together to avoid loss, and avoid placing it together with sharp objects to prevent scratches on the shell or damage to the USB port.

7. Warranty

Warranty: 180 days from delivery.

The warranty covers quality defects of the battery charger (such as poor contact, abnormal LED indicator, failure of protection functions, damage to USB port, inability to charge normally), not damage caused by improper use, violent collision, falling, disassembly, modification, moisture, high temperature and artificial damage, nor damage to batteries or cameras caused by incorrect use of the charger.

Manufacturer / Importer:

Shenzhen Dister Photography Equipment Co., Ltd.

4th Floor, West Block, Building 63, Majialong Industrial Zone, Nanshan District, Shenzhen City

PDF Download Tips: You can use tools such as PDFgear, Smallpdf or WPS to convert this document into a PDF file for download and storage (supports format retention and high-definition conversion).

(注：文档部分内容可能由 AI 生成)