

DSLRKIT Dual / Triple Flash Bracket Umbrella Holder Light Stand Shoe 1/4" Screw Product Manual

1. Product Basic Information

Product Name: DSLRKIT Dual / Triple Flash Bracket Umbrella Holder Light Stand Shoe 1/4" Screw

Product Specification: This product is a professional multi-functional flash bracket, branded DSLRKIT, designed to support dual or triple flash units simultaneously, integrating umbrella holder, light stand shoe and 1/4" standard screw connection functions, which is an essential auxiliary accessory for studio and outdoor flash photography. The bracket adopts a high-strength aluminum alloy frame, through precision CNC machining and anti-oxidation surface treatment, featuring sturdy durability, corrosion resistance, wear resistance and lightweight characteristics (only 150-180g), which is easy to carry and install without adding excessive burden to the light stand. It is equipped with 2-3 standard hot shoe mounts (compatible with most DSLR cameras, flash units, speedlites and flash triggers on the market), each hot shoe mount is equipped with a locking knob to fix the flash unit firmly, preventing slipping or shaking during use. The integrated umbrella holder (diameter 8mm-10mm) is compatible with most standard photographic umbrellas (such as white transparent umbrellas, silver reflective umbrellas), realizing simultaneous installation of flash and umbrella to adjust light quality and softness. The bottom of the bracket is designed with a standard 1/4" threaded hole, which can be quickly connected to light stands, tripods, ball heads and other supports (matching the 1/4" screw of most photographic supports), ensuring stable installation. Each flash mount supports 360° free rotation and 180° tilt adjustment, with adjustable locking force, allowing photographers to flexibly adjust the flash angle and light direction according to shooting needs. The product is suitable for studio photography, portrait photography, product photography, outdoor shooting and other scenarios that require multi-light collaborative lighting, helping to create rich light effects.

Note: All information in this manual must be consistent with the product detail page, outer packaging and actual products to avoid non-compliance due to information inconsistency. The product's aluminum alloy frame, hot shoe mounts, locking knobs, umbrella holder and internal connecting components comply with EU RoHS 2.0 Directive (2011/65/EU) hazardous substance restrictions, and do not contain prohibited harmful substances (lead, mercury,

cadmium, hexavalent chromium, PBBs, PBDEs, DEHP, BBP, DBP, DIBP, etc.). It is strictly compatible with flash units, umbrellas and light stands that match the size (1/4" screw, 8mm-10mm umbrella holder) and load capacity (single flash load $\leq 500\text{g}$, total load $\leq 1.5\text{kg}$); do not use it for overweight or mismatched equipment to avoid bracket deformation or equipment damage.

2. Product Description & Usage Instructions

2.1 Product Function

This product is a multi-functional dual/triple flash bracket from DSLRKIT, integrating flash mounting, umbrella fixing and light stand connection, mainly used to realize multi-flash collaborative lighting and light quality adjustment in photographic shooting. Its core functions include four aspects: first, multi-flash compatibility - equipped with 2-3 standard hot shoe mounts, which can simultaneously install dual or triple flash units, flash triggers or small LED lights, meeting the needs of multi-light lighting and helping photographers create layered and rich light effects that cannot be achieved by a single flash. Second, integrated umbrella holder - the built-in umbrella holder (8mm-10mm diameter) can fix standard photographic umbrellas (transparent, reflective), realizing the combination of flash and umbrella, which can soften the light of the flash, reduce harsh light spots, and improve the texture of the shooting subject, which is an essential function for studio and portrait photography. Third, flexible angle adjustment - each hot shoe mount supports 360° horizontal rotation and 180° vertical tilt adjustment, and the locking knob can fix the adjusted angle, allowing photographers to freely adjust the light direction of each flash according to the shooting scene and subject, achieving precise light control. Fourth, universal connection - the bottom 1/4" standard threaded hole is compatible with most light stands, tripods and ball heads on the market, which can quickly connect and fix the bracket, ensuring the stability of the entire lighting system. In addition, the lightweight and sturdy aluminum alloy material ensures portability and durability, adapting to both studio fixed shooting and outdoor mobile shooting; the anti-slip and anti-oxidation design of the hot shoe mounts and umbrella holder enhances the service life and stability, which is widely used in professional and amateur photography scenarios.

2.2 Usage Steps

1. Preparation: Check that the product is intact, the aluminum alloy frame is free of deformation, scratches or corrosion, the hot shoe mounts are intact, the locking knobs are flexible and adjustable, the umbrella holder is smooth and free of debris, and the 1/4" threaded hole is clean and free of damage. Confirm that the flash units, umbrellas and light stands to be used match the product specifications (1/4" screw, 8mm-10mm umbrella holder, load $\leq 1.5\text{kg}$); check that the equipment is clean and free of faults.

2. Connection to Light Stand/Tripod: Screw the 1/4" screw of the light stand or tripod into the threaded hole at the bottom of the bracket, and tighten it firmly to ensure that the bracket is stably connected to the support, without looseness or shaking. If using a ball head, first connect the ball head to the light stand, then connect the bracket to the ball head to realize more flexible angle adjustment of the entire bracket.
3. Installation of Umbrella (if needed): Insert the handle of the standard photographic umbrella (8mm-10mm diameter) into the umbrella holder of the bracket, adjust the depth of insertion according to the shooting needs, and tighten the locking knob on the umbrella holder to fix the umbrella firmly, ensuring that it does not shake or slip during use.
4. Installation of Flash Units: Unscrew the locking knob of the hot shoe mount (select the required number of mounts according to the number of flashes), insert the flash unit or flash trigger into the hot shoe mount, align the mounting slot, and gently tighten the locking knob to fix the flash. Repeat the operation to install other flash units (do not install more than 3 flash units at the same time). Adjust the angle of each hot shoe mount (rotate or tilt) to the desired light direction, and tighten the locking knob to fix the angle.
5. Use & Adjustment: After installation, turn on the flash units and adjust the flash parameters according to the shooting needs. During shooting, if you need to adjust the light direction, gently loosen the corresponding hot shoe locking knob, adjust the angle, and then tighten it; if you need to adjust the umbrella position, loosen the umbrella holder locking knob to adjust, then tighten it. Avoid excessive force when adjusting to prevent damage to the bracket or equipment.
6. Disassembly & Storage: After shooting, first turn off the flash units, unscrew the hot shoe locking knobs, and gently take down the flash units or triggers. Unscrew the umbrella holder locking knob and take out the umbrella. Unscrew the bracket from the light stand or tripod. Clean the bracket with a dry soft cloth to remove dust or fingerprints on the surface, hot shoe mounts, umbrella holder and threaded hole. Store the bracket, flash units and umbrella in a dry, clean and shockproof storage bag, away from direct sunlight, high temperature, humidity and corrosive substances, and avoid placing heavy objects on the bracket to prevent deformation.

2.3 Usage Restrictions

1. This product is strictly used for flash units, umbrellas and light stands that match the specifications: 1/4" threaded connection, 8mm-10mm umbrella holder, single flash load $\leq 500\text{g}$, total load $\leq 1.5\text{kg}$; it cannot be used for overweight equipment, non-standard umbrellas (diameter $>10\text{mm}$ or $<8\text{mm}$) or supports with non-1/4" screws, otherwise it may cause bracket deformation, loose installation, or equipment falling and damage.
2. Do not use excessive force when installing, disassembling or adjusting the locking knobs (hot shoe, umbrella holder, threaded connection); over-tightening may damage the locking

mechanism, hot shoe mounts or threaded hole; under-tightening may cause equipment slipping or falling, resulting in damage.

3. Do not use the product in humid (relative humidity $\geq 90\%$), high-temperature (above 60°C), low-temperature (below -10°C) or highly corrosive environments; avoid direct sunlight, rain, water splashing or contact with corrosive substances (such as acid, alkali, seawater), to prevent corrosion of the aluminum alloy frame, aging of the locking mechanism, or damage to the hot shoe mounts and threaded hole.

4. Do not disassemble, modify or cut the bracket by yourself (including disassembling the hot shoe mounts, umbrella holder or locking mechanism), and do not place heavy objects on the bracket or use it to hit other objects, otherwise it may cause deformation of the frame, damage to the locking mechanism or loss of functionality.

5. This product is a photographic lighting auxiliary accessory; do not use it for other purposes (such as lifting heavy objects, connecting non-photographic equipment), and do not install more than 3 flash units at the same time, to avoid overloading the bracket and causing deformation or damage.

6. Do not use the product if the hot shoe mount is loose, the locking knob fails or the threaded hole is damaged; these parts are key to fixing the equipment, and damaged parts may cause the flash or umbrella to fall, resulting in equipment damage.

3. Safety Warnings & Precautions

Warning! Please read and follow all warnings and precautions carefully to avoid damage to the product, flash units, umbrellas, light stands, or personal injury caused by improper use. The bracket is used to fix precision photographic equipment; improper use may cause the equipment to fall, resulting in serious damage.

1. This product is made of metal and has small components (such as locking knobs); it is not suitable for children under 36 months old to use alone; keep it away from children to prevent accidental swallowing, scratching or hitting injuries.

2. Do not disassemble, modify, cut or puncture the bracket by yourself; if there is a fault (such as deformation, loose hot shoe mount, failed locking knob, damage to the umbrella holder or threaded hole), stop using it immediately and contact after-sales service for professional maintenance. Unauthorized disassembly will void the warranty and may cause damage to the photographic equipment.

3. When installing and disassembling the flash units, umbrellas and bracket, place the equipment on a flat, stable and soft surface (such as a camera bag or soft cloth) to avoid accidental falling of the flash or umbrella, resulting in damage.

4. Before shooting, check the tightness of all locking knobs (hot shoe, umbrella holder, threaded connection) again to ensure that all parts are firmly fixed; do not start shooting if

there is any looseness, to avoid the flash, umbrella or bracket falling during operation.

5. When carrying the bracket with equipment installed, hold the light stand firmly with one hand and assist in supporting the bracket with the other hand; do not hang the equipment by the bracket alone, to avoid excessive stress on the bracket and threaded connection, resulting in damage.

6. When storing or transporting the product, avoid collision, extrusion or falling; do not mix it with other sharp or heavy objects to avoid scratching the aluminum alloy surface, damaging the hot shoe mounts, locking mechanism or threaded hole.

7. If the hot shoe mount is loose, the locking knob fails or the threaded hole is damaged, stop using it immediately and replace it with a professional matching part; do not use the damaged bracket to avoid equipment falling.

4. EU Compliance Information

4.1 Compliance Mark & Relevant Certifications

1. CE Mark: This product complies with the requirements of the EU General Product Safety Regulation (GPSR) (EU) 2023/988 and relevant EU safety standards for photographic accessories. The CE mark is clearly visible on the product body (aluminum alloy surface) or outer packaging, with a size not less than 5mm, no deformation or fading, and is permanently attached, which is convenient for EU market supervision and inspection.

2. RoHS Compliance: This product complies with the EU RoHS 2.0 Directive (2011/65/EU) and subsequent amendments, including the 10 core controlled substances (lead, mercury, cadmium, hexavalent chromium, PBBs, PBDEs, DEHP, BBP, DBP, DIBP). The content of hazardous substances in the aluminum alloy frame, hot shoe mounts, locking knobs, umbrella holder and internal connecting components meets the EU limit requirements (cadmium $\leq$ 0.01%, others $\leq$ 0.1%), without containing prohibited harmful substances. Relevant test reports and material declarations (MSDS/SDS) are retained for supervision and inspection, and a complete traceability chain from raw materials to finished products is established, avoiding non-compliance risks such as excessive lead content.

4.2 EU Authorized Representative (EC REP) Information

Company Name: CET PRODUCT SERVICE LTD.

Address: Osterholzallee 144, 71636 Ludwigsburg, Germany

Contact Information: Tel:+497-1416432236; Email address:info.cetservice@gmail.com

Note: The EU authorized representative information must be consistent with the signed agreement, and false or expired EU representative information is strictly prohibited. The EU authorized representative is responsible for receiving and handling inquiries and supervision

matters from EU market supervision departments on behalf of the manufacturer, and assisting in providing relevant compliance documents (such as DoC, material declaration, test reports) when required.

4.3 Applicable EU Directives & Standards

1. EU General Product Safety Regulation (GPSR) (EU) 2023/988
2. Restriction of Hazardous Substances Directive (RoHS 2.0) 2011/65/EU[3]
3. This product meets the relevant harmonized standards of the EU for photographic lighting accessories, including safety standards for metal and plastic products, and the technical documents (including Declaration of Conformity (DoC), material declaration, safety test report, RoHS test report, etc.) are kept for at least 10 years for inspection by EU market supervision departments, in line with EU compliance document retention requirements.

5. After-Sales Guarantee

1. Warranty Period: In accordance with AliExpress platform requirements, the minimum warranty period is 30 days; it is recommended to provide a 90-day warranty period for this product to improve customer trust.
2. Warranty Scope: During the warranty period, if the product has quality problems (such as deformation of the aluminum alloy frame, loose hot shoe mount, failed locking knob, damage to the umbrella holder or threaded hole, or non-compliance with EU RoHS/GPSR standards) under normal use, we provide free replacement or refund services. The warranty does not cover damage caused by man-made factors (disassembly, modification, improper use, collision, extrusion, falling, contact with corrosive substances or water, over-tightening the locking knob), natural wear and tear, or damage caused by using non-compliant equipment.
3. After-Sales Contact: 【Please fill in your AliExpress store customer service email or AliExpress store link; it is not recommended to use domestic mobile phone numbers】
4. Complaint Handling: For product quality or compliance-related complaints, we will respond within 48 working hours and provide a reasonable solution (replacement, refund, technical guidance, return and exchange) in accordance with EU regulations and AliExpress platform rules. For complaints involving EU compliance issues, we will provide relevant technical documents and certification materials to assist in handling.

6. Other Instructions

1. Language Description: This manual is in English, which meets the AliExpress EU market language requirements. AliExpress has launched an AI translation function, which can

automatically translate this manual into other EU official languages to meet the language requirements of different EU member states.

2. Disposal Instructions: This product is mainly made of recyclable aluminum alloy and metal components. After use, please dispose of it in accordance with the EU WEEE Directive (Waste Electrical and Electronic Equipment Directive) and local environmental protection regulations. Do not discard it at will; aluminum alloy parts and metal components should be sorted and recycled separately to avoid environmental pollution, in line with EU RoHS and environmental protection requirements, and ensure compliance with EU waste disposal regulations.

3. Document Update: This compliance manual will be updated in a timely manner in accordance with the changes of EU regulations (such as RoHS, GPSR) and AliExpress platform rules. The latest version shall prevail.

4. Compliance Commitment: We solemnly commit that this product and its packaging, instructions fully comply with the relevant regulations of the EU (including GPSR, RoHS 2.0) and AliExpress platform. If there is any non-compliance, we will bear all corresponding responsibilities (including product removal, fines, compensation for losses, etc.).

Manufacturer: Shenzhen Dister Photography Equipment Co., Ltd.

Manufacturer Address: 4th Floor, Building 63, Majialong Industrial Zone, Nanshan District, Shenzhen City

(注：文档部分内容可能由 AI 生成)