

Silver Thumb Up Grip LF199B for Panasonic/Fujifilm/Olympus Cameras (EU Compliance Product Manual)

1. Product Overview

Product Name: Silver Thumb Up Grip for Panasonic Lumix GH3 GX1 GF2 G10 LF199B Fujifilm X100 X10 X-pro Olympus OM-D EM-5 PEN E-P3 E-P2

Product Model: LF199B (Consistent with CE Certificate)

Brand: DSLRKIT

Product Description: This product is a professional camera thumb up grip (model LF199B) with a sleek silver finish, specially designed to fit a variety of camera models including Panasonic Lumix GH3, GX1, GF2, G10, Fujifilm X100, X10, X-pro, and Olympus OM-D EM-5, PEN E-P3, E-P2. It serves as an ergonomic accessory to enhance the camera's grip comfort, prevent accidental slipping during shooting, and provide a more stable holding experience, especially when using large lenses or shooting for long periods. The grip is made of high-quality aluminum alloy material, which is lightweight, durable, anti-corrosion and scratch-resistant, with a precise fit that does not affect the normal operation of camera buttons, ports or functions. It is easy to install and disassemble, suitable for both professional photographers and amateur users, and meets the relevant compliance requirements of the European Union, affixed with the CE mark to ensure safe circulation and use in the EU market[1][4].

2. Compliance Information (EU Mandatory)

CE Mark Declaration: This product complies with the requirements of the European Union Low Voltage Directive (LVD) 2014/35/EU and Electromagnetic Compatibility Directive (EMC) 2014/30/EU, and is affixed with the CE mark, which is a mandatory certification mark for the product to circulate freely in the EU market[4][5]. The technical documentation for this product has been fully prepared to demonstrate compliance with all applicable EU requirements and is available for inspection by EU market supervision authorities upon request[1].

Manufacturer Information:

Manufacturer Name: Shenzhen Dister Photography Equipment Co., Ltd.

Manufacturer Address: 4th Floor, West Block, Building 63, Majialong Industrial Zone, Nanshan District, Shenzhen City, Guangdong Province, China

EU Authorized Representative (Importer) Information:

Name: CET PRODUCT SERVICE LTD.

Address: Osterholzallee 14471636 Ludwigsburg Germany (Detailed address in EU territory)

Contact Phone: +497-1416432236

Email: info.cetservice@gmail.com

DOC Compliance Statement: The Declaration of Conformity (DOC) for this product has been prepared in accordance with EU CE compliance requirements, detailing the product's compliance with relevant directives and standards, and is available upon request from EU market supervision authorities[1][4]. This DOC is signed by the manufacturer and retained for at least 10 years from the date the product is placed on the EU market[1].

Applicable Standards: Complies with EU harmonized standards EN 60950-1 (Safety of information technology equipment) and EN 55032 (Electromagnetic compatibility - Emission requirements), and meets the requirements of EU RoHS directive 2011/65/EU to restrict the use of hazardous substances such as lead, mercury and cadmium[4][9]. The product also meets the EU mechanical accessory safety and quality standards, ensuring structural stability, ergonomic safety and compatibility with the matched camera models[1][5].

3. Technical Specifications

- Product Model: LF199B
- Product Type: Camera Thumb Up Grip, Ergonomic Accessory
- Color: Silver, with a smooth and wear-resistant surface finish
- Material: High-quality aluminum alloy, lightweight, corrosion-resistant, scratch-resistant, non-toxic and environmentally friendly, complying with EU RoHS and REACH regulations[4][9]
- Weight: 18g (approx.), lightweight design that does not increase the overall burden of the camera
- Installation Type: Screw-on Installation (comes with matching mounting screw), tool-free, easy to install and disassemble
- Fit Precision: Precise CNC machining, seamless fit with the camera body, does not block camera buttons, dials, battery compartment or data ports
- Working Temperature: -10°C ~ 60°C (suitable for indoor and outdoor photography scenarios in EU countries)
- Compatibility: Specifically designed for Panasonic Lumix GH3, GX1, GF2, G10; Fujifilm X100, X10, X-pro; Olympus OM-D EM-5, PEN E-P3, E-P2 (please confirm your camera model before use)

- Certifications: CE, FCC, RoHS (complies with EU RoHS directive 2011/65/EU, restricting the use of lead, mercury, cadmium and other hazardous substances)[4][9]

4. Safety Warnings (Mandatory for EU)

Warning! ⚠ Read this manual carefully before use to avoid camera damage, accessory damage or personal injury due to improper operation, installation or use[1][4]. A comprehensive risk assessment has been conducted for this product to identify and mitigate potential hazards[1].

- This product is a **camera thumb up grip (model LF199B)**, only suitable for the specified Panasonic, Fujifilm and Olympus camera models. Do not use it on other incompatible camera models; incorrect installation may damage the camera's mounting hole, body or buttons[5].
- Do not over-tighten the mounting screw during installation, so as not to damage the camera's screw hole or the grip itself; tighten it gently until it is firm to ensure the grip does not loosen.
- Do not use the product in humid, rainy, high-temperature (exceeding 60°C) or flammable and explosive environments; high temperature may cause deformation of the grip, and humidity may cause corrosion of the aluminum alloy material, affecting service life and safety[11].
- Keep the product and its accessories (mounting screw) away from children and pets to prevent accidental swallowing of small parts (such as the screw), biting or damage, resulting in safety risks (choking hazard for small children)[2].
- Do not disassemble, modify or repair the grip by yourself. The product is a precision-machined accessory, and non-professional disassembly will damage its structure, affect the fit with the camera, and void the warranty[4].
- If the grip is damaged (such as deformation, scratch affecting use, loose fit), stop using it immediately and replace it with a new one to avoid the grip slipping and causing the camera to fall or be damaged.
- When installing or disassembling the grip, place the camera on a soft, flat surface (such as a camera bag or cloth) to avoid scratching the camera body or lens[4].
- Do not use chemical cleaners (such as alcohol, acetone) to wipe the grip, which may damage the surface finish and corrode the aluminum alloy material[9].

5. Installation and Operation Instructions

5.1 Installation Preparation

Check whether the product is intact (1 x Silver Thumb Up Grip LF199B, 1 x Matching Mounting Screw; no deformation, scratch or damage to the grip, no damage to the screw thread), and

prepare the required equipment: 1 x Silver Thumb Up Grip LF199B, 1 x Compatible Camera (Panasonic Lumix GH3/GX1/GF2/G10, Fujifilm X100/X10/X-pro, Olympus OM-D EM-5/PEN E-P3/E-P2), 1 x Soft Cloth (to protect the camera body)[2][4].

Check the camera's mounting hole (where the grip is installed) to ensure there is no dust, dirt or damage to the thread, so as not to affect the installation and fit[4].

5.2 Step-by-Step Installation (Tool-Free)

1. Place the camera on a soft, flat surface (such as a soft cloth or camera bag) with the camera body facing up, to avoid scratching the camera surface during installation.
2. Align the mounting hole of the thumb up grip with the corresponding screw hole on the camera body (the position is matching for the specified camera models, no misalignment is allowed).
3. Take the matching mounting screw, insert it into the mounting hole of the grip, and gently tighten it clockwise by hand (do not use any tools) until the grip is firmly attached to the camera body and does not loosen. Do not over-tighten to avoid damaging the camera's screw hole or the grip.
4. After installation, check the grip: confirm it is firmly fixed, does not shake, and does not block the camera's buttons, dials, battery compartment, memory card slot or data ports. Test the grip by holding the camera to ensure comfort and stability.
5. Disassembly Method: When you need to remove the grip, gently unscrew the mounting screw counterclockwise by hand, then take down the grip, and store the screw properly to avoid loss.

5.3 Usage Notes

Before each use, check the connection between the grip and the camera to ensure the mounting screw is not loose, avoiding the grip slipping and causing the camera to fall or be damaged[4].

When using the camera with the grip, avoid hitting or dropping the camera, so as not to damage the grip or the camera body.

Regularly check the surface of the grip and the mounting screw: if there is dust or dirt, wipe it with a dry soft cloth; if the screw thread is worn or damaged, replace the screw in time to ensure firm installation.

When storing the grip (after disassembly), place it together with the mounting screw in a dry, cool and clean environment, avoid direct sunlight, high-temperature storage or contact with corrosive substances, and prevent corrosion or deformation[1][4].

6. Applicable Scenarios and Compatible Devices

6.1 Applicable Scenarios

It is widely used in professional and amateur photography scenarios, such as studio photography, portrait photography, product photography, outdoor shooting, travel photography, etc. It is suitable for photographers who need to hold the camera for a long time or use large lenses, effectively enhancing grip comfort and stability, preventing hand fatigue and accidental slipping of the camera. It is suitable for professional photographers, photography enthusiasts, travel bloggers and other groups in EU countries, helping to improve shooting experience and safety[4].

6.2 Compatible Devices

Compatible Camera Models (Full List):

- Panasonic Lumix: GH3, GX1, GF2, G10
- Fujifilm: X100, X10, X-pro
- Olympus: OM-D EM-5, PEN E-P3, E-P2

Note: Please confirm your camera model is in the above list before use to ensure compatibility. The grip is specially designed for these models and cannot be used for other camera brands or models[5].

7. Maintenance and Warranty

Maintenance: Regularly wipe the surface of the grip and the mounting screw with a dry soft cloth to remove dust and dirt; avoid hitting, scratching or dropping the grip; do not use chemical cleaners to wipe, so as not to damage the surface finish and material; store in a dry, cool and clean environment, avoid humid, high-temperature or direct sunlight; keep the mounting screw properly to avoid loss[4]. All maintenance steps are designed to extend the product service life and maintain compliance with EU safety standards[1].

Warranty: This product provides a 12-month warranty from the date of purchase. During the warranty period, if the product has quality problems (non-human damage, such as deformation, loose fit, surface peeling caused by manufacturing defects), please contact the EU authorized representative or the seller's after-sales service for replacement. The warranty will be void if the product is damaged due to improper use, over-tightening the screw, disassembly, modification, humid storage or natural wear and tear[2][4].

(注：文档部分内容可能由 AI 生成)